

**FUSES  
CARLINES R-W**

<b>CAVITY ONE (1)</b>	<b>20 Amps</b>	Ignition Lamp Time Delay Relay Glove Box Lamp Headlamp-on Buzzer Trailer Running Lamps Relay Coil	
Brake Warning Lamp Window Lift Safety Relay Temperature Gauge (Standard Cluster) Fuel Gauge (Standard Cluster) Oil Pressure Lamp (Standard Cluster) Voltage Limiter (Standard Cluster) Seat Belt Lamp Seat Belt Relay Seat Belt Buzzer Deck Lid Release Solenoid			
<b>CAVITY TWO (2)</b>	<b>20 Amps</b>		
Horn Horn Relay Key In Buzzer Clock			
<b>CAVITY THREE (3)</b>	<b>20 Amps</b>		
Stop Lamps Dome and Aft. Dome Trunk Lamp Hazard Flasher (Includes) Stop Lamps Front Turn Signal Lamps Turn Signal Indicator Lamps			
<b>CAVITY FOUR (4)</b>	<b>20 Amps</b>		
Ignition Lamp Map Lamp Tail Lamps Cigar Lighter License Lamp Parking Lamp Instrument Lamps (Cavity Five) Side Marker Lamps			
		<b>CAVITY FIVE (5)</b>	<b>5 Amps</b>
		Cluster Lamps Radio Lamp Stereo Cassette Lamp A/C or Heater Control Lamp Gear Selector Lamp Ash Receiver Lamp Accessory Switch Lamps	
		<b>CAVITY SIX (6)</b>	<b>20 Amps</b>
		Rear Defogger Air Conditioning Clutch Tachometer Feed (Rallye Cluster) Fuel Gauge (Rallye Cluster) Oil Gauge (Rallye Cluster) Temperature Gauge (Rallye Cluster) Voltage Limiter (Rallye Cluster)	
		<b>CAVITY SEVEN (7)</b>	<b>20 Amps</b>
		Heat Blower Motor Air Conditioning Blower Motor	
		<b>CAVITY EIGHT (8)</b>	<b>20 Amps</b>
		Radio Back Up Lamps Reverse Gear Indicator Lamp Turn Signal (Includes) Stop Lamps Front Turn Signal Lamps Turn Signal Indicators Trailer Back-up Lamps Relay Coil	

**IN-LINE FUSES AND CIRCUIT BREAKERS (R-W)**

<b>Fuses</b>	<b>Amps</b>	<b>Fuses</b>	<b>Amps</b>
Tailgate Lock Solenoid .....	20	Stop Lamp .....	10
Heater and Air Conditioning Blower Motor with Tilt Column .....	20	Trailer Tow Package .....	30
<b>Circuit Breakers</b>	<b>Amps</b>		
Power Tailgate Window and/or Power Windows .....	30		
Tailgate Lock Solenoid .....	15		

## LIGHT BULBS

<b>CARLINES</b>	<b>W</b>	<b>W (Rallye)</b>
Air Conditioner Control .....	1892	1892
Ash Receiver .....	**161	**161
Auxiliary Switch Lamp .....	—	—
Back-up Lights .....	1156(2)	1156(2)
Brake System Warning Indicator ...	158	57
Cassette Tape Deck .....	1891	1891
Clock .....	*	*
Cornering Lights .....	—	—
Courtesy Lamp .....	—	—
Dome Lamp .....	1004	1004
Door Ajar Indicator .....	—	—
Fender Mounted Turn Signal Indicator .....	161(2)	161(2)
Front Park and Turn Signal .....	1157 or 1157NA	1157 or 1157NA
Gear Selector Indicator (Column) ..	**161	**161
Gear Selector With Console .....	**57	**57
Glove Compartment .....	1891	1891
Headlamp Switch Rheostat Valve ..	15 OHMS	15 OHMS
High Beam Indicator .....	158	57
Instrument Cluster and Speedometer .....	**158(4)	**57(7)
Ignition Lamp .....	1445	1445
License Light .....	67 (Sta. Wag. 168)	67
Low Fuel Indicator .....		
Map and Courtesy Lamp .....	562	562
Oil Indicator .....	158	—
Radio—AM and AM with Tape .....	**1816	**1816
Radio—AM—FM Stereo .....	**1816	**1816
Reverse 4 Speed Transmission Indicator .....	53	53
Sealed Beam—Hi-Beam (No. 1) .....	4001	4001
Sealed Beam—Hi-Lo Beam (No. 2) .	4000	4000
Seat Belts Indicator .....	1892	1892
Side Marker .....	168(4) Station Wag. Front 168(2) Rear 1893	168(4)
Stereo Indicator .....	1445	1445
Switch Lighting .....	161(3)	161(3)
Tail, Stop and Turn Signal .....	1157(4) or Sta. Wag.(2)	1157(4)
Trunk and/or Under Hood Lamp ...	1003—1004	1003—1004
Turn Signal Indicator (Panel) .....	158(2)	57(2)
Tail Light (Only) .....		

\*Included in Instrument Cluster Lighting.

\*\*Headlamp Rheostat Dimming.